



**Assembly notes:**

- When installing the USB power components, cut the PCB trace between the pads of P13.
- Test diodes (D14-D17) to ensure they are placed with the correct orientation.

For more information: <http://greatscottgadgets.com/tc13badge>